

Home > POWER (Power tools) > Jig Saw > DJS101AB

DJS101AB



Cordless Jig Saw + 2 batteries + 1 charger + 1 fabric toolbag

- + Speed variator trigger for precise speed control
- + Electric brake quickly stops the blade rotation when the trigger is released
- + Compatible with "T" and "U" shank Jigsaw blades (not included)
- + Adjustable base beveling from 0 45 degrees (left/right)
- + 4-Position orbital action for smooth cutting in a variety of materials.
- + LED to illuminate the work area
- + Ideal for sawing wood, aluminum and steel
- + Storage of the blades in the base of the saw.
- + Consumable not included







m7	Series	Content
_	DJS101	x1
	DB1850P	x2
4	DC1840A	x1
Ø	BA80129	x1